

CAUTION

Always be sure the weight is **tightly threaded** into the bottom of the i-Wob2.

140 inch-lbs torque recommended.



AGRICULTURAL IRRIGATION | A Hunter Industries Company
Learn more. Visit senninger.com

PRECAUCIÓN

Siempre asegúrese de que el peso sea **bien enroscado** en la parte inferior del i-Wob2.

Se recomienda un par de torsión de 140 pulgadas-lbs.



AGRICULTURAL IRRIGATION | A Hunter Industries Company
Aprende más. Visite senninger.com