

# CAUTION

Always be sure the Universal Magnum Weight™  
is **tightly threaded**  
into the bottom of the i-Wob®2.

*140 inch-lbs torque recommended.*

**Hunter®** | *Agricultural Irrigation*

MANUFACTURER OF SENNINGER® PRODUCTS

[hunterirrigation.com/agriculture](http://hunterirrigation.com/agriculture)

25 WC-EN 03

# PRECAUCIÓN

Asegúrese siempre de que el  
Universal Magnum Weight™ esté **firmemente**  
**enroscado** en la parte inferior del i-Wob®2.

*Se recomienda un par de torsión de 140 pulgadas-lbs.*

**Hunter®** | *Riego Agrícola*

FABRICANTES DE PRODUCTOS SENNINGER®

[hunterirrigation.com/agriculture](http://hunterirrigation.com/agriculture)

25 WC-ES 03